



1 Place the template and make preholes/drilling guides



2 Drill the four holes



3 a) For plaster remove the two top screws and keep the two bottom ones with a 5mm gap to the wall

b) For wood and concrete start with the two bottom screws with a 5mm gap to the wall



4 Place the GP15 on the two bottom screws



5



6 Use a long bit to tighten the two top screws



7 Tighten the two bottom screws



8 Place the tray



9 Close the door



10 To finish, put on the lid

